Installation Preparation

PARTS SUPPLIED IN INSTALLATION PACKAGE:



Junction Box Cover and #10 Hex-Head Junction Box Screw 3/8" Iona



Drain Hose (approximately 58" long) (on some models)



Hose Clamp

Drain Hose Hanger




#8-18 x 5/8" Phillips Special Head Screws (to secure dishwasher to underside of countertop or to side cabinets)





Toekick (pre-installed **Plug Buttons** on some models)



Handle and 1/8" Allen wrench (on some models)



Bottle Jets clips (on some models)



Literature

MATERIALS YOU WILL NEED:

Mounting Brackets (for wood countertops or side cabinets)

Insulation Pieces

(on some models)



90° elbow (3/4" hose internal thread on one end, opposite end sized to fit water supply)



UL-listed Wire Nuts (3)



Masking Tape

MATERIALS YOU WILL NEED FOR NEW INSTALLATIONS ONLY:



Hot Water Line-3/8" minimum, copper tubing (including ferrule, compression nut) or GE Appliances Part # WX28X326, flexible braided hose



Hand Shut-Off Valve (recommended)



Optional -12' Drain Hose - WD24X10065 4' Drain Hose - WD24X10062



Waste Tee for house plumbing, if applicable



Air Gap for drain hose, if required



Coupler for optional drain hose



Hose Clamp (if needed for optional drain hose)



Electrical Cable or Power Cord Kit WX09X70910 (5.4 Ft) or WX09X70911 (7.9 ft) depending on your installation

Level

Gloves



Strain Relief for electrical connection

TOOLS YOU WILL NEED:



Screwdriver






Safety Glasses



Flashlight




Bucket to catch water when flushing the line




for skid removal)

Carpenter's Square

















Tubing Cutter

Dishwasher Installation

STEP 6 POSITION WATER LINE AND HOUSE WIRING

 Position water supply line and house wiring on the floor of the opening to avoid interference with base of dishwasher and components under dishwasher.

